

Premium

SANDWICH MAKER
SANDUCHERA



Premium

Manual de uso y cuidado
Precauciones importantes

Este producto es para uso doméstico únicamente.

This product is for domestic use only

Use & Care Manual
Important Safeguards

MODEL: PSM276
MODELO: PSM276

INSTRUCCIONES DE USO

1. Cuando lo utilice por primera vez, limpie la superficie de las placas con un paño húmedo y séquelo. Luego esparza un poco de mantequilla, margarina o aceite de cocina.
2. Conecte el enchufe en el tomacorriente.
3. Cuando la sandwichera está lista, después de unos 5 minutos, la luz de apto para cocinar se encenderá. (O la luz piloto se apagará en tostadoras con una sola luz).
4. Abra completamente la sandwichera. Ponga una rebanada de pan en la placa inferior de la sandwichera con la mantequilla en contacto con la placa.
5. Ponga el relleno, presionando contra la rebanada.
6. Ponga la otra rebanada con la mantequilla por encima y cierre la sandwichera cuidadosamente. Puede salir vapor por lo lados de la sandwichera, tenga mucho cuidado para evitar quemaduras.
7. Asegure las dos partes de la sandwichera con el seguro. NOTA: durante el proceso la luz piloto se encenderá y apagará a medida que el termostato se activa para mantener la temperatura.
8. El sánduche estará listo en 2-3 mins, o hasta que alcance el tostado deseado. Abra la Sandwichera para retirar el sánduche con una espátula plástica o de madera. Nunca use utensilios metálicos, pues pueden dañar la superficie antiadherente.
9. Cierre la sandwichera para conservar el calor si va a preparar más sánduches o desconéctela si ha terminado.

Limpieza

- Después de su uso y antes de limpiarlo, desconecte el enchufe, y espere a que la tostadora se enfríe.
- Limpie el interior y los bordes de la placa con una toalla de papel absorbente de cocina o un paño suave.
- Si el relleno es difícil de quitar, vierta un poco de aceite sobre el plato y limpie después de 5 minutos, cuando el relleno se haya ablandado.
- Limpie el exterior con un paño ligeramente húmedo para garantizar que no entre humedad, aceite o grasa dentro de las ranuras.
- No limpie el interior o exterior con cualquier material abrasivo ya que esto dañará el acabado.

NO SUMERJA EN AGUA U OTRO LÍQUIDO

SANDWICH MAKER

MODEL: SSD21

USE & CARE MANUAL



(CAUTION: Hot surface): The surfaces are liable to get hot during use.

IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed, including these:

1. Read all instructions before using.
2. This appliance is for household use only.
3. Do not touch hot surfaces. Use handles and knob.
4. To protect against electrical shock, do not immerse cord, plugs, or appliance in water or other liquid.
5. Unplug from outlet when not in use and before cleaning.
6. Allow to cool before putting on or taking parts off.
7. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. No user-serviceable parts included. Please return appliance to the nearest authorized service facility for information on examination, repair, or adjustment.
8. The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
9. Do not use outdoors or in very humid environments.
10. Do not let cord hang over edge of table or counter, or touch hot surfaces.
11. Do not place on or near a hot gas or electric burner, or in a heated oven.
12. Preheat the unit about 2 minutes before using.
13. Close supervision is necessary when any appliance is used by or near children.
14. Do not use the unit near gas or other inflammable materials (such as benzene, paint thinner, sprays, etc.)
15. This product should not be used in the immediate vicinity of water, such as bathtub, washbowls, swimming pool etc. Where immersion or splashing could occur.
16. Do not leave the appliance unattended when switched on.
17. Use appliance only for intended use.
18. Always attach plug to appliance first, then plug cord in the wall outlet.
19. To disconnect, remove plug from wall outlet.
20. The appliance is only to be operated in the closed position.
21. This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
22. Children should be supervised to ensure that they do not play with the appliance.
23. The appliance is not intended to be operated by means of an external timer or separate remote-control system.
24. The temperature of accessible surfaces may be high when the appliance is operating.

SAVE THESE INSTRUCTIONS

A short power-supply cord is provided to reduce the hazards resulting from entanglement or tripping over a long cord; an extension cord may be used with care, however, the marked electrical rating should be at least as great as the electrical rating of this appliance. The extension cord should not be allowed to drape over the counter or tabletop where it can be pulled on by

children or tripped over.

INSTRUCTIONS OF USE

1. When using for the first time, wipe the surface of the platens with a damp cloth and dry with cloth, tissue etc. Then smear the platen with butter, margarine or cooking fat.
2. Fit the plug into the wall socket.
3. When the Sandwich Maker is ready after about 5 mins the ready-to-cook light will come on. (or light will go off in toasters with only one light).
4. Fully open the Sandwich Maker. Place a slice of bread in the bottom half with the buttered side against the platen.
5. Fill the sandwich, pressing the bottom half into the platen.
6. Place on the top slice with the buttered side up and carefully close the two parts of the toaster together. Do not force shut. Steam will be ejected from between the platens, please be careful to avoid burns.
7. Lock the two halves with the wire clip whilst toasting is taking place. NOTE-During toasting the warning light will cycle on and off while the thermostat keeps the toaster at the right temperature.
8. Your sandwich will be ready in 2-3 mins, or longer to suit your taste. Open the toaster and remove sandwich using plastic or wooden spatula. Never use metal knife as this may damage the non-stick coating.
9. Close the lid to preserve the heat until ready to toast the next sandwiches.
10. Prepare further sandwiches if required whilst the one is cooking.
11. After use, remove the plug from the wall socket.

Cleaning

- After use and before cleaning, remove plug, wait for toaster to cool.
- Wipe the inside and the edges of the platen with kitchen absorbent paper toweling or a soft cloth.
- If filling is difficult to remove, pour a little cooking oil onto the platen and wipe off after 5mins when the filling has softened.
- Wipe the outside with only a slightly moistened cloth ensuring that no moisture, oil or grease gets inside the cooking slots.
- Do not clean the inside or outside with any abrasive scouring pad or steel wool as this will damage the finish.

DO NOT IMMERSE IN WATER OR ANY LIQUID

SANDUCHERA

MODELO: SSD21

MANUAL DE USO Y CUIDADO



(ADVERTENCIA: Superficie caliente): Las superficies son susceptibles de calentarse durante el uso.

PRECAUCIONES IMPORTANTES

Cuando use aparatos eléctricos tenga en cuenta precauciones básicas de seguridad, incluyendo las siguientes:

1. Lea todas las instrucciones antes de usar
2. Este producto es para uso doméstico únicamente.
3. No toque las superficies calientes. Utilice las manijas o perillas.
4. Para protegerse contra descargas eléctricas, no sumerja el cable, los enchufes ni el aparato en agua u otro líquido.
5. Desconecte del tomacorriente tanto cuando no esté en uso como antes de limpiarlo
6. Deje enfriar antes de manipular partes removibles.
7. No opere ningún aparato con un cable o enchufe dañado, después de un mal funcionamiento o si ha sido dañado de alguna manera. No hay piezas que puedan ser reparadas por el usuario. Por favor, devuelva el aparato al distribuidor autorizado más cercano para obtener información sobre revisión, reparación o ajuste.
8. Utilice únicamente accesorios recomendados por el fabricante del electrodoméstico.
9. No usar al aire libre o en zonas muy húmedas.
10. No permita que el cable cuelgue de la mesa o mostrador ni que toque ninguna superficie caliente.
11. No ponga el electrodoméstico cerca o sobre un horno o estufa.
12. Precaliente la unidad al menos 2 minutos antes de usarla.
13. Si el aparato es utilizado cerca de niños, preste especial atención y supervisión.
14. No opere el electrodoméstico cerca de materiales inflamables o cerca del agua.
15. No deje el aparato desatendido mientras este encendido.
16. Utilice el aparato únicamente para los fines para que fue diseñado.
17. Si el cable es removible, siempre conecte primero al aparato y luego al tomacorriente.
18. Para desconectar remueva el enchufe del tomacorriente.
19. Este aparato no está diseñado para ser utilizado por personas (incluidos niños mayores de 8 años) con capacidades físicas, sensoriales o mentales reducidas, o sin experiencia y conocimiento, a menos que sean supervisados o instruidos acerca del uso del aparato por una persona responsable de su seguridad.
20. Asegúrese que los niños no usen este aparato como un juguete.
21. Este producto no está diseñado para utilizarlo con un temporizador o control remoto.
22. La temperatura de las superficies accesibles puede ser elevada cuando el aparato está en funcionamiento.

GUARDE ESTE MANUAL DE INSTRUCCIONES

El cable suministrado es corto con el fin de disminuir los riesgos de enredos o tropiezos, un cable de extensión puede ser utilizado con cuidado, sin embargo, tenga en cuenta que su graduación eléctrica sea suficiente para la potencia eléctrica de este aparato. No permita que la extensión cuelgue del mostrador o mesa en donde pudiera ser jalado por niños o causar tropiezos.